

# Geberit Montage

Rückschlagklappe darf nur bei Automaten ohne Rückschlagventil eingebaut werden.

Le clapet anti-refoulement doit uniquement être monté sur les machines n'ayant pas de clapet anti-refoulement intégré.

La valvola di non ritorno a cerniera può essere montata soltanto in utensili senza valvola antiritorno.

Terugslagklep alleen inbouwen indien de wasmachine géén ingebouwd terugslagventiel heeft.

